

How to Replace the Batteries in Your LOCI Asset Tracker

Asset Tracker Battery Replacement Guide

Before you begin, you will need:

- A LOCI Asset Tracker
- 3x AA Energizer Ultimate Lithium Batteries
- A small philips head screwdriver
- A small plastic, wooden, rubber, or non-metal prying tool (optional)



Step 1

Unscrew the six screws on the back cover of your LOCI Asset Tracker device.



Step 2

Remove the batteries with a non-metal prying tool (if you have one) or your fingers. Keep them out for 10 seconds and put them back in,

A red light will flash on the back of the green circuit board for a few minutes to signify that the batteries are working and that the device is connecting to the network.

Please Note: Asset Trackers ping 3x per day with 8-hour intervals e.g. if you input the batteries at 9:04am they will ping at 5:04pm, 1:04am and 9:04am.



Step 3

Replace the back cover and screw it on with the six screws you removed in step 1.

Battery Life

The battery life of your LOCI Asset Trackers can be found in two ways:


- via Notifications (battery critical or battery needs replacing)
- Under 'My Assets' in the Argus Tracking platform.

Notifications

From the Argus Dashboard, head to **Settings > Notifications** to set up a notification when batteries are critical or need replacing.

My Assets

From the Argus Dashboard, head to 'My Assets', and change the view to medium icons (the first option) to see the battery life of your asset trackers in the bottom right-hand corner of the Asset Profile overview page.



Need Help?

Log a Support Ticket
support@argustracking.com